


# External Attach Frame MD-500

**Installation Manual** 



Tyler - External Attach Frame
For MD-500 Series Helicopters
FAA STC # SR02067LA



## PLEASE RETURN THIS MANUAL WITH EQUIPMENT



Tyler Camera Systems 14218 Aetna Street Van Nuys, California 91401 • USA www.tylertech.net • 800-390-6070 • FAX (818) 989-0423 (818) 989-0423





MODEL: <u>MD 369</u> JOB #:

REPORT #:

MDINSTAL-005

DATE:

1/3/07

## EXTERNAL ATTACH FRAME INSTALLATION MANUAL FOR MD 369 D, E, F, FF, 500N, 600N MODEL

PREPARED BY:	R. LAMB	# OF PAGES:	
	1/3/07		
CHECKED BY:	G. WOOD	# OF DRAWINGS:	0
	1/3/07		
APPROVED BY:			

## **REVISIONS**

DATE	PAGES AFFECTED	REVISION LETTER		APPROVAL
1/3/07	ALL	NC	ORIGINAL ISSUE	

# **External Attach Frame**

Installation





## Upper Support Bracket - Permanent Installation to Hard-Point


- 1. Place Bracket on the aircraft hard-point just above rear door, and align 4 holes in Bracket with threaded inserts.
- 2. Temporarily attach Bracket using 4 hex-head bolts # AN3-5A and 4 washers AN960-10 (white dotted circles).
- 3. Use a china marker or pencil to outline Bracket on aircraft skin, then remove Bracket.
- 4. Locate and mark 4 rivets on aircraft skin (yellow circles ).
- 5. Drill out and remove all 15 rivets within the marked area on aircraft.
- 6. Locate the 4 rivets marked with dotted circles, and dimple aircraft skin at these holes only (using proper tools).
- 7. Install 4 flush rivets # CR3212-5-3 in the aircraft skin (dimpled holes only).
- 8. Temporarily re-install the Bracket with using the 4 bolts and washers.
- 9. From the inside of aircraft, use a punch to mark the back of the Bracket for the rivet holes to be drilled.
- 10. Remove Bracket, and drill the holes as marked on the back side, for cherry max rivets # CR3213/4-3.
- 11. De-burr the holes on both sides.
- 12. Clean and prime all surfaces of the Bracket and wait for primer to dry.
- 13. Install a small amount of 870 B1/2 proseal between the aircraft skin and Bracket.
- 14. Permanently attach Bracket with 11 cherry max rivets, and 4 bolts with wahers (torque to 50-70 inch pounds).
- 15. Clean up proseal with alcohol or another approved cleaning solvent.

Repeat above steps for Right Side Bracket installation.

Aircraft Left Side Hard-Point Above Rear Door







Hard-point forward of rear door



Hard-point aft of rear door

1 • INSTALL THE THREE "T" BRACKETS WITH THE AN3-5A HEX HEAD BOLTS SUPPLIED. TORQUE TO 50-70 INCH POUNDS



## 2 • INSTALL THE MAIN SUPPORT TUBE AND SECURE WITH 3/8 X .75 QUICK PIN



3/8" QUICK PIN


UPPER SUPPORT
TUBE

3 • INSTALL UPPER SUPPORT ROD, ONE SIDE TO THE UPPER "T" BRACKET AND THE OTHER TO THE MAIN SUPPORT TUBE WITH TWO (2) 3/8" X .75 QUICK PINS

REAR DIAGONAL TUBE




4 • INSTALL REAR DIAGONAL SUPPORT TUBE, ONE SIDE TO THE REAR "T" BRACKET AND THE OTHER TO THE REAR OF THE MAIN SUPPORT TUBE WITH TWO (2) 3/8" X .75 QUICK PINS



5 • INSTALL SHORT SUPPORT TUBE, ONE SIDE TO THE REAR DIAGONAL TUBE AND THE OTHER TO THE REAR OF THE MAIN SUPPORT TUBE WITH TWO (2) 3/8" X .75 QUICK PINS




6 • ONCE ALL THE TUBES ARE CONNECTED, YOU CAN START ADJUSTING THE SUPPORT TUBES TO GET THE MAIN TUBE'S ATTUTUDE ABOUT 10 DEGREES ABOVE LEVEL. ONCE THIS IS ADJUSTED, LOCK ALL JAM NUTS ON THE SUPPORT TUBES





7 • INSTALL THE QUICK RELEASE FLOOR PLATE. THE FLOOR PLATE LOCATION IS AT THE OPERATOR'S DISCRETION, HOWEVER, MAKE SURE THAT THE PLACEMENT WILL NOT INTERFERE WITH ANY COCKPIT CONTROLS.






1/2" X 3" QUICK PIN




 $8 \bullet \,$  INSTALL QUICK RELEASE HOOK ASSEMBLY WITH THE 1/2" X 3" QUICK PIN



9 • INSTALL RELEASE HANDLE ASSEMBLY INTO QUICK RELEASE FLOOR PLATE, MAKING SURE THE QUICK RELEASE CABLE IS ROUTED TO STAY CLEAR OF ANY COCKPIT CONTROLS, PILOT OR CO-PILOT FUNCTIONS



Hook Release Handle Lock down knobs



10 • CHECK FOR PROPER RELEASE FUNCTION AFTER INSTALLATION IS COMPLETE

# **END OF INSTALLATION**

#### United States Of America

## Department of Transportation - Federal Abiation Administration

## Supplemental Type Certificate

Number SR02067LA

This Certificate issued to

Tyler Camera Systems 14218 Aetna Street Van Nuys, California 91401

Certifies that the change in the type design for the following product with the limitations and conditions therefor as specified hereon meets the airworthiness requirements of Part 6 of the Civil Air Regulations & Part 27 of the Federal Aviation Regulations. Certification basis is set forth in Type Certificate Data Sheet H3WE Original Product Type Certificate Number:

Make: MD Helicopters Inc. (MDHI)

Model: 369D, 369E, 369F, 369FF, 500N

Description of Type Design Change: . Installation of External Attach Frame in accordance with FAA Approved Tyler Camera Systems Master Drawing List No. MDEF-001, Revision A, dated June 28, 2007, for MDHI models 369D, 369E, 369F, 369FF, 500N, or later FAA approved revision. The Installation Manual is No. MDINSTAL-005 dated January 3, 2007 or later FAA approved revision and the Instructions for Continued Airworthiness is in MDEF-005, dated 14 August 2007 or later FAA accepted revision.

Limitations and Conditions. Approval of this change in type design applies to the aircraft models listed above only. The installation should not be incorporated in any aircraft unless it is determined that the interrelationship between this installation and any previously approved configuration will not introduce any adverse effect upon the airworthiness of the aircraft. If the holder agrees to permit another person to use this certificate to alter the product, the holder shall give the other person written evidence of that permission. (Continued)

This certificate and the supporting data which is the basis for approval shall remain in effect until surrendered, suspended, revoked or a termination date is otherwise established by the Administrator of the Federal Aviation Administration.

Date of application : September 7, 2006

Date reissued :

Date of issuance :

September 4, 2007

Date amended :

By direction of the Administrator

Mechael E. Meil (Signature) or Manager, Airframe Branch

Los Angeles Aircraft Certification Office

#### United States Of America

## Bepartment of Transportation - Federal Abiation Administration

## Supplemental Type Certificate

(Continuation Sheet)

INSTRUCTIONS: The transfer endorsement below may be used to notify the appropriate FAA Regional Office of the transfer of this Supplemental Type Certificate.

The FAA will reissue the certif	ficate in the name of the transferee and forward it to him.
	TRANSFER ENDORSEMENT
Transfer the ownership o	f the Supplemental Type Certificate Number
to (Name of transferee)	
(Address of transfer)	(Number and street)
	(City, State, and Zip code)
from (Name of grantor) (Pri	int or type)
(Address of grantor)	(Number and street)
-	(City, State, and Zip code)
	censing agreement):
Date of Transfer:Signature of gran	tor (In ink):

Any alteration of this certificate is punishable by a fine of not exceeding \$1,000, or imprisonment not exceeding 3 years, or both.

#### United States Of America

## Bepartment of Transportation - Federal Abiation Administration

## Supplemental Type Certificate

(Continuation Sheet)

Number SR02067LA

Limitations and Conditions: (Continued)

The FAA Approved Rotorcraft Flight Manual Supplement No. Document Number EF-RFM-001, dated August 28, 2007, or later FAA Approved revisions, for the External Attach Frame is required.

A copy of this Certificate must be maintained as part of the permanent records for the modified aircraft. If the holder agrees to permit another person to use this certificate to alter the product, the holder shall give the other person written evidence of that permission.

- END -



## **FAA APPROVED** ROTORCRAFT FLIGHT MANUAL SUPPLEMENT FOR THE MD HELICOPTERS MODEL MD-500D, 500E, 530FF, & 520N WHEN EQUIPPED WITH THE **EXTERNAL ATTACH FRAME**

AL #:

The information in this supplement is FAA approved material and must be attached to the FAA Approved MD-500 series Rotorcraft Flight Manual when the aircraft has been modified by the installation of Tyler Camera Systems External Attach Frame in accordance with:

## STC # SR 02067 LA

The information contained herein supplements or supersedes the information in the basic Rotorcraft Flight Manual only in those areas listed herein. For limitations, Procedures and Performance information not contained in this Supplement, consult the basic Rotorcraft Flight Manual.

FAA Approved:

Manager, Flight Test Branch, ANM-160L

Federal Aviation Administration

Los Angeles Aircraft Certification Office

Transport Airplane Directorate

FAA Date: August 28, 2001

STC Number SR 02067 LA

## LOG OF PAGES

Rev No.	Pg No	Date	Description of Change	FAA Approved
Initial Issue	1-6	28 Aug 2007	Initial Issue	Mgr, Flight Test Branch ANM-160L, FAA, Los Angeles ACO, Transport Airplane Directorate  DATE: 8-28-2007

STC Number SR 02067 LA

## **TABLE OF CONTENTS**

SECTI	ION	PAGE
SECTI	ION 1 – GENERAL	2
SECTI	ION 2 – LIMITATIONS	5
1.1	AIRSPEED	5
1.2	MAXIMUM WEIGHT LIMIT	5
1.3	LATERAL CG LIMITS	5
2. SI	ECTION 3 – EMERGENCY PROCEDURES	5
3. SI	ECTION 4 – NORMAL PROCEDURES	6
4. SI	ECTION 5 - PERFORMANCE	6
5. SI	ECTION 6 – WEIGHT AND BALANCE	6
	TABLE OF FIGURES	
FIGUE	RE	PAGE
	E 1. VIEW OF INSTALLED FRAME	
	E 2. LEFT SIDE INSTALLATION OF FRAME	
	E 3. HOOK RELEASE HANDLES	
FIGUR	E 4. HOOK RELEASE	4

FAA Approved: 28 August 2007

Page 1 of 6

Supplement to the MD Helicopters RFM for Models MD-500D, 500E, 530FF, & 520N when modified with the MD 5 External Attach Frame

STC Number SR 02067 LA

## **SECTION 1 - GENERAL**

The Tyler Camera Systems MD-5 External Frame consists of the steel tubular frame members that attach to the existing hard point on the roof and side of the rotorcraft.



Figure 1. View of Installed Frame

Document Number EF-RFM-001

Supplement to the MD Helicopters RFM for Models MD-500D, 500E, 530FF, & 520N when modified with the MD 5 External Attach Frame

STC Number SR 02067 LA

The frame is attached to the hard points using quick release pins for ease of installation as shown in Figure 2.



Figure 2. Left Side Installation of Frame

The External Attach Frame can be used in conjunction with STC # SR 01682 LA for the MD-5 Cargo Rack Installation

## CAUTION

Lateral CG can be easily exceeded with heavy weights on the External Attach Frame

See Limitation Section for CG Limits

FAA Approved: 28 August 2007

Page 3 of 6

Supplement to the MD Helicopters RFM for Models MD-500D, 500E, 530FF, & 520N when modified with the MD 5 External Attach Frame

STC Number SR 02067 LA




Figure 3. Hook Release Handles (Control Closet between Pilots)



Figure 4. Hook Release

FAA Approved: 28 August 2007

Page 4 of 6

Supplement to the MD Helicopters RFM for Models MD-500D, 500E, 530FF, & 520N when modified with the MD 5 External Attach Frame

STC Number SR 02067 LA

## **SECTION 2 – LIMITATIONS**

### 1.1 AIRSPEED

#### CARGO INSTALLED

Reduce to hover flight to load cargo. Vne with Cargo attached = 15 knots

### NO CARGO INSTALLED

Reduce the published Power – On V<sub>NE</sub> 30 KIAS with the External Frame.

#### 1.2 REQUIRED CREW

A second pilot is required in the front seat to jettison the load when anything is attached to the attach frame hook.

#### 1.3 MAXIMUM WEIGHT LIMIT

Maximum Weight 415 pounds on hook

#### 1.4 LATERAL CG LIMITS

The lateral center of gravity limit is  $\pm$  5.0 inches with airspeed limits published above.

## 2. SECTION 3 – EMERGENCY PROCEDURES

Jettison load from hook by pulling out and back on the release handles.

FAA Approved: 28 August 2007

Page 5 of 6

STC Number SR 02067 LA

## 3. SECTION 4 - NORMAL PROCEDURES

No Change

## 4. SECTION 5 - PERFORMANCE

No Change

## 5. SECTION 6 - WEIGHT AND BALANCE

The weight and balance data must be considered for each flight.

The load on the external attach frame must be considered.

## CAUTION

Lateral CG can be easily exceeded with heavy weights on the external attach frames. Compute the aircraft weight and balance before flight with loads on the frames.

The longitudinal CG of the external frame hook is Sta 96.9 inches

The lateral CG of the external frame hook is:

Left: - 50.0 inches Right: + 50.0 inches

FAA Approved: 28 August 2007

Page 6 of 6